

# AirWave<sup>®</sup>2

**Additional information to manual**  
***-Software version 2022-***



Version 23.05.2022


## New features

1. Locking machine
2. Programming
3. Reminder (technical Level)

### 1. Locking Machine

The control panel can be locked to prevent setting changes by unauthorized persons.




Touch  on the home screen to enter the lock code.




Choose **Lock/unlock machine** and enter the code "1-2-3".




Touch  to confirm and return to the start screen.



Touch  to return to the start screen without the lock function.



**Change Lock code via Technican Level: *ATTENTION:*** The loss of the lock code can only be remedied by re-installing the software, which is a cost-intensive process that can only be fixed by a technician on site or by sending the machine to our factory.

***This is NOT covered by the warranty.*** (Tel.:07150/ 92396-0, [www.floeter.com/support/](http://www.floeter.com/support/))



A small icon of a padlock indicates that the control panel is locked.

In this state, it is only possible to


Insert film , start air cushion production  and


stop .

Temperature, air volume or production length cannot be changed. For this, the control panel must be unlocked again. Touch "SET" enter the code and touch "ENT" to confirm and return to the start screen.


## 2. Programming machine

**Five presets** with temperature, air volume, production speed and pre-blowing time are programmable for quick selection.

Via  you get to the selection page.




Select **Preset Programs** for quick selection of a pre-setting, touch the associated number (1, 2, 3, 4, or 5) until you are returned to the home screen or touch the

number shortly and press .

Settings are automatically applied to the start screen.

**Factory-set:** **M1** for type 7.1 PE film 20 $\mu$ m; **M2** for type 7.2 PE film 20 $\mu$ m; **M3** for type 8.3 PE film 20 $\mu$ m



To program or change a preset, select **Change preset** in the selection menu and enter the code "4-5-6" and then

press .

Now you can adjust the values and save



with .

### 3. Reminder

As a **reminder to replace wear parts** (brown PTFE belt, blade and blue performance belt, counterpressure plate), the reminder function can be activated via the technical level.





Select **Technician Level** for setting the reminder function, enter the **code 1-3-5**.



Select **Reminder** in the next screen on page 3/3 to activate the function **(on / off)**.

Press **ENT**.

**For a probable change of the predefined reminder values, please call our service department (07150/92396-0).**



With **Remind me later**, the service is postponed for another period of time. To ensure the durability of the machine, the service should be carried out in time. Video instructions can be found after scanning the QR code.